

Model: Citroen C2

INSTALLATION MANUAL:

- plate should not interfere with any vehicle's units and components. Remove regular plastic dust quard
- 2.Fix special fasteners to the radiator's beam with bolts M 8x20 -(A)

Installation manual

- 3. Loosen the two bolts (located on the front axle beam) fastening the cross tube and remove the tube.
- 4. Put the rear part of the skid plate on the tube's place and likil together with the tube with bolts -(8). 5. Fix the front part of the skid plate to already installed fasteners, with bolt M 8x30 -(C).

6 Tighten all screwinints

OPERATING CONDITIONS: Engine bay and transmission elements skid plate has been designed to operate in conditions specified by vehicle's producer. Cases of crush or driving into obstacles, at a speed should be excluded during exploitation. In case of head-on crush it is necessary to assure in absence of damages of vehicle's components and units and availability of roadworthingse, on cartified senion stations

WARRANTY:

Warranty period - 1 year.

WARRANTY TERMS:


The skid plate should be installed on a vehicle with undamaged body and load-bearing elements (vehicle, which hads

never been involved in road traffic accident): There are no mechanical damages of the skid plate resulting from head-on crush. All requirements to skid plate installation should be satisfied:

There are no mechanical damages of powder coating. Producer does not bear liability for damages caused to the vehicle, health and life of people in case of installation and exploitation terms violation. Producer has a right to introduce changes into the skid plate construction.



The Quality Management System of LLC Metalloproduktsia has been audited by Bureau Veritas Certification and conforms to requirements of the ISO 9001:2008 standard.





Skid plate for:engine bay and transmission case





LIST OF PARTS

NO.	NAME
1	Towing lug
2	Special was
3	Washer 8
4	Bolt M 8x20

NO.	N
	Ta.

1	NAME	QTY.
ı	Bolt M 8x30	2
ı		
Ī		

Article: 05.0540/05.1295

M6x1.0	M8x1.25
	M6x1.0

washer

Thread	M6x1.0	M8x1.25	M10x1.5	M1
tening torque	9.8 Hu	24.0 Hw	47.0 Hu	81